

FIGURE 1




FIGURE 2




FIGURE 3




FIGURE 4




FIGURE 5B




FIGURE 6

VCR DVD	SELECT INPUT FOR V	
DVD		BOX
	VCR	
NONE	DVD	
NONE		•
NONE		•
NONE		
NONE	NONE	

FIGURE 7